

**Beta distribution**


The beta density function is defined over the interval  $0 \leq x \leq 1$  and it can be used to model proportions (e.g. the proportion of time a machine is under repair, the proportion of a certain impurity in a chemical product, etc.). The probability density function of the beta distribution is given by:

$$f(x) = \frac{x^{\alpha-1}(1-x)^{\beta-1}}{B(\alpha, \beta)}, \quad \alpha > 0, \beta > 0, 0 \leq x \leq 1.$$


where,

$$B(\alpha, \beta) = \int_0^1 x^{\alpha-1}(1-x)^{\beta-1} dx.$$

The shape of the distribution depends on the values of the parameters  $\alpha$  and  $\beta$ . When  $\alpha = \beta$  the distribution is symmetric about  $\frac{1}{2}$  as shown in the figure below:



When  $\alpha > \beta$  the distribution is skewed to the left and when  $\alpha < \beta$  it is skewed to the right (see next figure).



Even though  $x$  was defined in the interval  $0 \leq x \leq 1$ , its use can be extended to random variables defined over some finite interval,  $c \leq x \leq d$ . In this case we can simply rescale the variable using  $y = \frac{x-c}{d-c}$ , and  $y$  will be between 0 and 1.

It can be shown that

$$B(\alpha, \beta) = \frac{\Gamma(\alpha)\Gamma(\beta)}{\Gamma(\alpha + \beta)}.$$

Using this relation between the beta and gamma functions we can find the mean and variance of the beta distribution:

$$E(X) = \frac{\alpha}{\alpha + \beta}$$

and

$$\text{var}(X) = \frac{\alpha\beta}{(\alpha + \beta)^2(\alpha + \beta + 1)}.$$